

## Step by Step Guide to sealing your project

- 1) Ensure that all surfaces are clean and free of loose material or debris.
- 2) Gap sand should be allowed to settle and compact in the gaps in pavers.
- 3) Allow the surface to dry thoroughly – this will ensure best penetration is achieved.
- 4) Read directions for use on the sealer container before opening.
- 5) Apply directly from the container – do not dilute the sealer.
- 6) Use a low pressure spray unit, short nap roller or – for small areas – a brush to apply the sealer.
- 7) Ensure the entire surface area to be treated is covered.
- 8) Apply the second coat with in 30 min of the first coat.
- 9) Protect treated surfaces from rain for at least 6 hours.



## WHO ARE WE?

*Tech-Dry is an innovative manufacturer of sealers and treatments for protection of all kinds of concrete and masonry structures.*

## CONTACT US

*Tech-Dry Building Protection Systems  
177-179 Coventry Street  
South Melbourne - VIC 3205*

*Phone: 03 9699 8202  
Email: [info@techdry.com.au](mailto:info@techdry.com.au)*



*Distributed by:*

# Tech-Dry®



## MASONRY SEALERS

*Invisible penetrating  
silicone sealers for  
masonry surfaces*

